

1.972 / 2.06 WORKS
SUCCESS USB MONITOR PAGE CONNECTION

V.2.05 MA

DAVE THOMAS


(8.00)

TRIMBLE FIELD IQ CFX 750
MENU LAYOUT FOR:
V.2.14 Rate & Section Control Module

V 2.06 Master Switch & 12 Switch Box




SETTINGS SCREEN






IMPLEMENT





IMPLEMENT SETUP






MATERIAL SET UP


NOTE: Once a material is setup, it will appear in Material Assignment

*edit No of Rows
change to No of rows*






CONTROL SETUP






SECTION CONTROL SETUP





RATE CONTROL SETUP



THIS IS MINIMUM RATE THAT THE FLOW METER WILL




TRIMBLE FIELD IQ CFX 750

MENU LAYOUT FOR:

V.2.14 Rate & Section Control Module

V.2.06 Master Switch & 12 Switch Box

CALIBRATION SETUP





ADVANCED SETUP

